

WE-03: Current Voltage Characteristics through Grains and Grain Boundaries of High-k Dielectric Thin Films Measured by Tunneling Atomic Force Microscopy

Katsuhisa Murakami¹, Mathias Rommel², Vasil Yanev², Anton J. Bauer², and Lothar Frey^{1,2}

¹Chair of Electron Devices, University of Erlangen-Nuremberg, Cauerstrasse 6, 91058 Erlangen, Germany

²Fraunhofer Institute for Integrated Systems and Device Technology (IISB), Schottkystrasse 10, 91058 Erlangen, Germany

Motivation

In our previous study¹

- high leakage current paths through high-k dielectric films (HfSi₃O₈ and ZrO₂) were found to be located at the grain boundaries by tunneling atomic force microscopy (TUNA)
- Possible reasons for the larger leakage current through grain boundaries:
 - Different current conduction mechanisms for grains and grain boundaries.
 - Smaller thickness of grain boundaries compared to that of grains.




Purpose of this paper

- Measurements for local *I-V* curves at grains and grain boundaries of high-k dielectric films by TUNA in order to clarify the current conduction difference between the grains and grain boundaries of high-k dielectric films

¹V. Yanev, et al., Appl. Phys. Lett. 92, 252910 (2008).

TUNA principle



- Atomic Force Microscope (AFM) with a conductive probe operated in contact mode, probe tip acts as top electrode of a MIS structure
- DC bias voltage (*V*) is applied between tip and sample
- Leakage (tunneling) current through the dielectric layer is measured in dependence on *V*
- Extended TUNA amplifier (extremely sensitive to low currents): measurable current range: 40 fA to 12.3 pA (in the used sensitivity (1pA/V))

Experimental

Sample preparation

- | ALD HfSi ₃ O ₈ (8 nm) | ALD ZrO ₂ (5 nm) |
|---|-----------------------------|
| native oxide (1.1 nm) | native oxide (1.1 nm) |
| p-type Si | p-type Si |
- HfSi₃O₈ sample ZrO₂ sample
- HfSi₃O₈: RTA (1000 °C 60 s) to crystallize the films.
 - ZrO₂: RTA in Ar atmosphere at 450 °C for 30 s.

TUNA measurement

- Dimension ICON with NanoScope V controller (closed-loop system) and Extended TUNA module.
- Pt/Ir coated Si probe (nominal tip radius of 25 nm)
- For all local *I-V* measurements, substrate bias was ramped from 0 V to -10 V.

Experimental Parameters	HfSi ₃ O ₈	ZrO ₂
substrate voltage for TUNA current map (V)	-9.1	-2.7
tip velocity for TUNA current map (μm/s)	1.5	1.5
ramp rate for local <i>I-V</i> measurement (V/s)	0.5	0.25
deflection setpoint (V)	-0.9	2.0

High resolution TEM analysis

- FEI CM 300 system
- Cross sectioned ZrO₂ sample

Results and Discussion

HfSi₃O₈ sample




Figure 1. (a) TUNA topography map and (b) corresponding TUNA current map of the HfSi₃O₈ film. Scan size: 2 x 0.5 μm²

Topography map (Fig. 1(a))

- Crystalline grains can clearly be observed in the topography.
- Height of grain boundaries is lower than that of grains.

TUNA current map (Fig. 1(b))

- Clearly visible conductive structures correspond to grain boundaries in topography map.
- Two types of grain boundaries are observed:
 - boundaries with high leakage current (grain boundary A)
 - boundaries with low leakage current (grain boundary B)




Figure 2. Local TUNA *I-V* curves through grains and grain boundaries.

Local *I-V* curves (Fig. 2)

- Distribution of local *I-V* curves at grains has wide spread, while that at grain boundaries shows two tight spreads (i.e., A and B)
- The two types of spreads might be due to different current conduction mechanisms for grain boundaries A and B, respectively (see Fig. 1).

- Leakage currents through grain boundaries are found to start at lower voltages for spread A.
- It is, however, difficult to clarify the origin of the difference for the *I-V* curves between grains and grain boundaries because of the effect of the thickness variations on the *I-V* curves.

ZrO₂ sample




Figure 3. (a) Topography map of the ZrO₂ film measured by tapping mode AFM. Scan size: 500 x 500 nm². (b) HR-TEM image of the film.




Figure 4. TUNA current maps (a) before any local *I-V* measurement, (b) after the 1st local *I-V* curve at a grain boundary (spot 1), (c) after the 2nd local *I-V* curve at a grain (spot 3). Scan size: 1.33 x 0.5 μm².

Topography map (Fig. 3a) and HR-TEM image (Fig. 3b) of ZrO₂ film

- No crystal grains and smooth surface (RMS is 0.18 nm) observed by tapping mode AFM.
- HR-TEM image clearly shows nanocrystalline structure, and very smooth surface of ZrO₂ and underlying SiO₂.

TUNA current map before and after local *I-V* measurement at grain and grain boundaries (Fig. 4, Fig. 5 (b))

- Grains and grain boundaries can clearly be observed in the initial TUNA current map (Fig. 4 (a)):
 - Larger leakage current paths at grain boundaries in spite of the smooth surface of the ZrO₂
- Points where local *I-V* curves have been performed before, can clearly be observed in subsequent TUNA current maps:
 - Very high leakage current with an oscillating noise along the scan direction due to breakdown of the spots (Fig. 4 (b,c)).
- Resolution of the TUNA current map is not deteriorated after local *I-V* measurements.

Local *I-V* curves for the ZrO₂ film at grains and grain boundaries (Fig. 5 (a))

- Significant differences between curves at grains and grain boundaries.
- Leakage current through the grain boundaries is up to 8 times larger than that through the grains at a voltage of -3.5 V.




Figure 5. (a) local *I-V* curves for the ZrO₂ film at grains and grain boundaries. (b) TUNA current map after several local *I-V* measurements at grains and grain boundaries. Scan size: 1.33 x 0.5 μm².

Summary and Conclusions

HfSi₃O₈ film

- Topography map and leakage current distribution of the HfSi₃O₈ thin film could be simultaneously measured by TUNA.
- Leakage current through grain boundaries was found to be larger than that through grains.
- Two types of grain boundaries in terms of local *I-V* characteristics could be distinguished.

ZrO₂ film

- Major leakage current paths were located at the grain boundaries although surface morphology of the ZrO₂ film was rather smooth.
- Larger leakage current at grain boundaries is not due to a thickness variation of the film.
- I-V* curves exactly located at grains and grain boundaries could successfully be measured.
- Local *I-V* curves show a significant difference between grains and grain boundaries.



This work was partially funded by the German Federal Ministry of Education and Research (BMBF) (Contract No. 01M3089E) within the project UTTERMOST (UITimeTe Enablement Research on 32/28 nm MOS Technologies).

Contact:

Chair of Electron Devices, University of Erlangen-Nuremberg
Cauerstrasse 6, 91058 Erlangen, Germany
Telephone: +49 (0)9131 / 761-174
Telefax: +49 (0)9131 / 761-360
Email: katsuhisa.murakami@le.eei.uni-erlangen.de
Internet: www.le.eei.uni-erlangen.de