

ADVANCED CHARACTERIZATION OF FUEL CELL STACKS



photo Joscha Feuerstein

Stefan Keller

Fraunhofer Institute for Solar Energy Systems ISE

Hannover, April 4th 2019

www.h2-ise.com

www.ise.fraunhofer.com

Visit us at booth C58!

Business Area Hydrogen Technologies at Fraunhofer ISE



Department Thermochemical Processes (Dr. Achim Schaadt)

- Synthesis of H_2 and CO_2 to liquid energy carriers/fuels or chemicals (PtL)
- Catalytic evaporation of liquid hydrocarbons
- Life cycle assessment in the field of hydrogen technologies



Department Chemical Energy Storage (Dr. Tom Smolinka)

- Hydrogen generation by PEM water electrolysis
- Energy storage in H_2 systems and redox flow batteries
- Power-to-Gas: Interconnection of the power and gas grid








Department Fuel Cell Systems (Ulf Groos)

- Single cell and spatially resolved characterization of fuel cells and stacks
- Production research for membrane electrode assemblies and gas diffusion layers
- System technology: balance of plant and operating strategies

We are assisting fuel cell industry for over 25 years

- performance characterization
- life-time analysis
- local phenomena
- contamination effects
- climate tests
- testing balance-of-plant components



Our equipment for characterization of fuel cell stacks

Test bench, climate chamber and stack impedance system




Test bench

- 20 kW | 1 000 A | 150 cell voltage channels
- Gas supply: Anode 0.5 – 400 NI/min;
Cathode 1.5 – 1 600 NI/min
- Gas temperature: 30 – 100 °C
- Humidification: Dew point 20 – 90 °C
scrubber humidifier with dry bypass
- Cooling: 40 kW cooling / 6 kW heating |
max. 90 °C | 3,4 – 73 l/min
- Pressure control: 1.1 - 4 bara
- Automated operation 24 / 7 possible


Our equipment for characterization of fuel cell stacks

Fully automatic operation guarantees reproducible results




Our equipment for characterization of fuel cell stacks

Fully automatic operation guarantees reproducible results



Our equipment for characterization of fuel cell stacks

Fully automatic operation guarantees reproducible results



Our equipment for characterization of fuel cell stacks

Test bench, climate chamber and stack impedance system




Climate chamber

- Temperature range from -50 °C to +80 °C
-20 °C @ 10 kW_{th}
- Temp. tolerance: ± 1 K
- Humidity range from
+5 % r.H. to +95 % r.H. @ temperatures above
+10 °C
- Humidity tolerance: ± 3 %
- Internal dimensions 2 x 2 x 2 m³
- Supply of conditioned air up to 2 000 m³ / h
- Gas supply provided by test bench


Our equipment for characterization of fuel cell stacks

Freeze start capability of 20 cell short stack proven



Autostack CORE Evolution 2

- Less than 13 s to 50 % nominal power @ -20 °C



Our equipment for characterization of fuel cell stacks

Test bench, climate chamber and stack impedance system




Stack impedance system

- 150 V / 25 A
- 28 channels with synchronized measurement
- Frequency range 20 kHz – 0.01 Hz
- Pre-amplification to increase SNR
- Use of low inductance + low capacitive cabling

Our equipment for characterization of fuel cell stacks


Impedance data provides additional information about your stack



- Steady-state point
 (U_{ss}, i_{ss})
- Superimposed by small perturbation
 $i(t) = i_{ss} + i_{AC} \sin(2\pi f t)$
- Frequency dependent response
 $U(t) = U_{ss} + U_{AC} \sin(2\pi f t + \phi)$

Our equipment for characterization of fuel cell stacks


Impedance data provides additional information about your stack



- Steady-state point
 (U_{ss}, i_{ss})
- Superimposed by small perturbation
 $i(t) = i_{ss} + i_{AC} \sin(2\pi f t)$
- Frequency dependent response
 $U(t) = U_{ss} + U_{AC} \sin(2\pi f t + \phi)$

Our equipment for characterization of fuel cell stacks


Impedance data provides additional information about your stack




- Different frequencies address different processes
- Better separation of the various loss mechanisms
- In situ procedure

Our equipment for characterization of fuel cell stacks

Impedance data provides additional information about your stack




- Different frequencies address different processes
- Better separation of the various loss mechanisms
- In situ procedure




Our equipment for characterization of fuel cell stacks

Impedance data provides additional information about your stack




- Different frequencies address different processes
- Better separation of the various loss mechanisms
- In situ procedure



Join us at our booth C58 for a good cup of Freiburg roasted coffee!

Follow our talks @ Technical Forum also in YouTube channel of H2FC fair:

- Tuesday, April 2, 14:00 | Max Julius Hadrich: Pathways for Power-to-Liquid fuels and chemicals
- Wednesday, April 3, 13:00 | Ulf Groos: Characterization of fuel cell MEAs
- Thursday, April 4, 16:00 | Thomas Jungmann: Testing of fuel cell bop components in H₂ atmosphere




Fraunhofer-Institut für Solare Energiesysteme ISE

Stefan Keller, stefan.keller@ise.fraunhofer.de, www.ise.fraunhofer.de

Short circuit and isolation testing of fuel cell stacks

Ensuring the safety of your device



- MOSFET used for bounce-free circuit switching
- 100 kHz sampling rate
- High cable and bar section (5000 A for 20 ms) to avoid losses
- OCV_{max} 20VDC

